

**Zubehör:** Split-Range Einheit  
**Accessoire:** Unité domaine partiel  
**Optional extras:** Split-range unit  
**Accessorio:** Unità split-range  
**Accesorio:** Unidad Split-Range  
**Tillbehör:** Split-Range enhet  
**Toebehoren:** Split-range eenheid

**Montagevorschrift**  
**Instructions de montage**  
**Fitting instructions**  
**Istruzioni di montaggio**  
**Instrucciones de montaje**  
**Monteringsanvisning**  
**Montagevoorschrift**




**AVM ... S**  
**AVF ... S**  
**ASF ... S**  
**AXM ... S**  
**ASM ... S**

Installationsanweisung für die Elektrofachkraft  
 Notice d'installation pour l'électricien  
 Guidelines for the electrician  
 Informazioni per l'installatore elettrico  
 Instrucciones de instalación para el electricista  
 Installationsinstruktion för behörig elektriker  
 Instalatie aanwijzing voor de elektromonteur  
 Für den Einsatz in üblicher Umgebung  
 Pour usage dans un environnement normal  
 For use in normal environments

Per impiego in ambiente usuale  
 Para el uso en ambiente normal  
 För användning i normal miljö  
 Voor toepassing in normale omgeving


Darf nicht in Kombination mit dem 230V-Modul  
 (0372332001) verwendet werden.  
 Must not be used in combination with the 230V  
 module (0372332001).

No puede utilizarse en combinación con el  
 módulo 230V (0372332001).  
 Non deve essere utilizzato in combinazione  
 con il modulo 230 V (0372332001).  
 Ne pas utiliser avec un module  
 230 V (0372332001).  
 Mag niet in combinatie met de 230V-module  
 (0372332001) worden gebruikt.  
 Får inte användas i kombination med  
 230 V-modulen (0372332001).







2c

AVM ...S  
AVF ...S  
ASF ...S  
AXM ...S  
ASM ...S



3



$U_o = 0 \dots 8 \text{ V}$   
 $\Delta U = 3 \dots 10 \text{ V}$